

CODING

-124001







ISO 9001:2000
Certificate No. 2502



Read instruction carefully. Remove all wrapping material staples and straps from the carton. Refer hardware and furniture part list for guidance. Be sure you have all parts before you start assembling. Place all wooden furniture part a clean and flat soft surface, such as carpet or rubbermat to prevent from getting scratched.

Caution

KEEP ALL PARTS OUT OF REACH OF CHILDREN.

<p>(A) x 8</p>  <p>M8 x 70 mm</p>	<p>(B) x 8</p>  <p>M8 x 15 mm</p>	<p>(C) x 12</p>  <p>Screw 4 x 15 mm</p>	<p>(D) x 1</p>  <p>ALLEN KEY M4 FOR M6</p>
--	---	--	--

